

Operating manual



ASTRO EdgePAL U115
RF1.1 Channel Settings

Time: 24 Mar 2010 10:48:03 UTC, Up: 0d 19h 13m 05s, SW:3805 FW:0.2 HW:0
Name: ASTRO EdgePAL U114, Location: Headend in Cablecity, Contact: John Doe, admin@example.com

● ASTRO EdgePAL U114
● MgmA 192.168.1.144
● MgmB 192.168.5.144
● user is logged in

Input Selection

Property	Value
Transport Stream / Service	arte, ARD (SID:28724 Digital television)

Stream Selection

Property	Stream	PID (-TTX page)
PCR		401
Video	ISO/IEC 13818-2 Video	401
Audio A	ger ISO/IEC 11172 Audi	402
Audio B	ASTRO EdgePAL U114	
Teletext		
Subtitling		

ASTRO EdgePAL U115
Statistics

Time: 24 Mar 2010 12:03:23 UTC, Up: 0d 20h 26m 25s, SW:3805 FW:0.2 HW:0
Name: ASTRO EdgePAL U114, Location: Headend in Cablecity, Contact: John Doe, admin@example.com

● ASTRO EdgePAL U114
● MgmA 192.168.1.144
● MgmB 192.168.5.144
● user is logged in

Modulation

Property	Status	Value
Logout		
Main		
Test Gen		
IP RX		
IP RX1		
IP RX2		
IP RX3		
IP RX4		
TV System		
VPS		
WSS		
RF1.1		
RF1.2		
RF2.1		
RF2.2		

Ethernet bandwidth

Property	Management A (eth0) 100M	Management B (eth2) 1G	Data A (eth2) 1G	Data B (eth3) 1G
Transmit	0.085 Mbps	0.000 Mbps	0.000 Mbps	0.000 Mbps
Receive	0.032 Mbps	0.000 Mbps	148.141 Mbps	0.000 Mbps

Ethernet frames

Property	Data A (eth2) 1G	Data B (eth3) 1G
Total frames sent by host	2656	0
Total frames sent to host	3288	0

U 115 quad IP / PAL converter U 100 - 230 Base unit

General

This operating manual was created to provide the relevant instructions for operating the U 115. We expressly recommend reading this manual before installing or operating the device.

The ASTRO company confirms the information in this manual to be correct at the time of printing, but it reserves the right to make changes, without prior notice, to the specifications, the operation of the device and the operating manual. The ASTRO company is not responsible for printing errors. The contents of this operating manual are confidential and protected by copyright. This manual may not be reproduced in any form - not even in part - without prior written permission from the ASTRO company.

Pictograms and safety instructions

Pictograms are visual symbols with specific meanings. You will encounter the following pictograms in this installation and operating manual:



Warning about life-endangering situations due to dangerous electrical voltage or non-adherence to this manual.



Warning about various dangers to health, the environment or material.



Recycling: all of our packaging material (cardboard boxes, accompanying papers, plastic film and bags) is completely recyclable.

Used batteries must be disposed of at approved recycling points. Batteries must be completely discharged before being disposed of.



Electronic devices must not be disposed of with household waste, but rather – according to directive 2002/96/EG OF THE EUROPEAN PARLIAMENT AND OF THE COUNCIL from January 27, 2003, on waste electrical and electronic equipment – must be properly disposed of. When they are no longer of use, please bring these devices for disposal to one of the public collection points for this purpose.

Copyright notice

Some of the software of this product is third-party software, which was developed under several different licensing conditions. Detailed information concerning the licences can be found via the Web interface of the device.

The source code of the free parts of the software is distributed on request for an administration fee.

Please contact:

kontakt@astro-strobel.de
ASTRO Strobel Kommunikationssysteme
Olefant 1-3
D-51427 Bergisch Gladbach (Germany)
Tel.: (+49) 2204 405-0

All other parts of the software of this product are copyrighted by Astro Strobel Kommunikationssysteme GmbH.

© Copyright 2011 by Astro.



Table of contents

1	Figures.....	4
2	Introduction.....	5
	2.1 Description of functions	5
	2.2 Safety instructions	5
	2.3 Mounting instructions.....	5
	2.4 Potential equalisation / earthing.....	6
	2.5 Maintenance and repair	6
	2.6 Service tasks.....	6
	2.7 Technical data for mains supply.....	6
	2.8 Installing and coding the backplane	7
	2.81 Coding the backplane.....	7
	2.82 Installing the backplane.....	8
3	General introduction	9
	3.1 Connecting the U 115 to a PC / laptop.....	9
	3.2 The Web browser user interface	9
4	Login	10
5	Status.....	11
6	Settings for the IP interfaces, IP management and base device	12
	6.1 Configuration of the IP interfaces.....	13
	6.2 IP management configuration	13
	6.3 U 100 settings	14
	6.4 Saving and loading a configuration, default and reboot.....	14
7	Test generator	15
8	Configuration of the IP inputs.....	16
9	Configuration of the HF outputs	18
10	User management	20
11	Transport Stream (TS) Analyzer	21
12	Licensing	22
13	Software update / saving and loading a configuration	23
	13.1 Update using example of a TFTP server for Windows	24
14	System log.....	25
15	Statistics.....	26
16	Network properties.....	27
17	Logout	28
18	Technical data	29



1 Figure


The figures show the U 115 installed in the U 100 - 230 base device.



Control and data wheel, menu switch
 Display of management IP addresses, data IP addresses, status messages, etc.
 Status display

Status display for slots
 L = left
 M = middle
 R = right
 P = power supply

Data ports
 HF outputs
 Fan




230 V Power supply:

Mains supply
 Earthing connection
 Mains supply

Management ports

48 V Power supply:



Fuse
 Mains supply
 Earthing connection

2 Introduction

The instructions in chapter 2 mainly apply to the U 100 - 230 base device.

2.1 Description of functions

The U 100 series is used to convert IP data streams into CATV signals. The U 100-230 base device can accommodate up to three U 1xx signal converters, as well as up to two U 100-SNTs for supplying the voltage to the U 1xx signal converters. The U 115 receives up to four video data streams encapsulated according to the internet protocol (IP) and converts them into up to four standardised PAL output signals.

2.2 Safety instructions

Disconnect both mains plugs before opening the device!

The device must not be opened - for exceptions, see the maintenance and repair, and the service tasks! Power supply units must not be opened!

The device must be connected to a power supply with an earth contact, and should be positioned close to the mains socket.

The electrical system supplying current to the device, e.g. a house installation, must incorporate safety devices against excessive current, short-circuiting and earth leakages in accordance with EN 60950-1.

Both mains plugs are used to disconnect the device from the mains, therefore they must be easy to access and use at all times. The device is already in operation when one power unit is connected to the operating voltage. When the second power unit is also put into operation, one of the power units runs in idle mode as long as the other unit is supplying power to the device. The device may only be repaired by sending it to ASTRO along with a precise description of the error.

Displays indicate the status of the device operation, as well as the existence of DC voltages separate from the mains that are supplying the components of the device. However, operation displays that are not lit up in no way indicate that the device is completely disconnected from the mains or is voltage-free.

Read carefully:

EN 50 083 – Part 1, Safety requirements / No service tasks during electrical storms!

2.3 Mounting instructions

The U 100 base device may only be mounted using guide rails! If the device is only fastened by means of the screws in the front panel, this will damage the base device!

The outputs of the signal converter must not be operated without connecting a combining network or terminating impedance!

Protection from environmental factors:

The device must only be connected and operated in dry rooms. It must not be exposed to spraying or dripping water, or to similar phenomena. If condensation appears, wait until the device is completely dry. Objects containing liquid must not be placed on top of the device.

The permitted ambient temperature range is 0 ... 45°C (ETS 300 019-1-3 class 3.1).

Mounting environment:

The device is designed for operation in, preferably, metallically conductive 19" racks with sufficient air convection. It should be operated away from heat radiation and other heat sources. The device may only be installed in rooms in which the permitted ambient temperature can be adhered to, even under changing climatic conditions. To avoid trapped heat, it must be freely ventilated on all sides. You absolutely must avoid mounting the device in a niche or covering the ventilation openings.



2.4 Potential equalisation / earthing



The subscriber network must be earthed correctly in accordance with EN 50083-1, and must remain earthed even when the device is removed.
The potential equalisation on the U 100 is effected via the fastening plates of the device, or via the earthing connection on the back of the device. Devices within hand's reached must be incorporated into the potential equalisation among one another.

It is not permitted to operate the device without an earth conductor, device earthing or device potential equalisation!

2.5 Maintenance and repair



Disconnect both mains plugs before opening the device!
The device must not be opened other than for repair purposes. In general, power units must not be opened. Repairs may only be carried out at the plant or at workshops, or by persons, authorised by ASTRO Strobel Kommunikationssysteme GmbH.



Read carefully: DIN VDE 0701- 0702, Repairs

Note: The device must not be opened by the user!

2.6 Service tasks

The following tasks, in which screw connections have to be opened, can be performed by appropriately instructed service personnel: removal and installation of signal converters (e.g. U 115) and power units, also in the operating mode of the U 100.

Replacing power units

After the screws on the cover of the power unit chamber (ASTRO logo) are removed, the power units can be pulled out by hand, forwards along the mounting panel.
When power units are being installed, there should be no contact with the ventilator or the fan grid,
and only the mounting panel attached to the power unit should be used.
When the tasks are complete, the cover of the power unit chamber must be replaced; continuous operation of the device is not permitted without this cover.



Note: Do not put your hand or any objects into the power unit chamber.

The U 100 must only be operated with the original power unit(s)!

Replacing converter modules:

Converter modules can be pulled outwards after the safety screw on the front panel has been unscrewed.

2.7 Technical data for the mains supply (U 100 SNT 230 V version)

Mains voltage:	100 – 240 V
Mains frequency:	50 / 60 Hz
Current consumption:	1.4 – 0.7 A per power unit
Protection class according to EN 60529:	IP 20
Permitted ambient temperature range:	0 ... 45°C
Secondary fuse in U100-230:	T3,15A L 250 V IEC 60127-2/3
Secondary fuses in U114:	SMD, various values

2.8 Installing and coding the backplane

The scope of delivery of every U 1xx signal converter includes a backplane to create the physical connection between the signal converter and the base device. Both the mains HF connections and the network connections are connected to this backplane. The temperature controlled fan for cooling the U 1xx signal converter is located on the backplane.

2.8.1 Coding the backplane

To correctly define the position of the backplane, and thus the position of the related signal converter in the U 100 base device, the jumper on the board of the backplane, which is described in the following section, must be configured.




Figure 1: Coding the backplane using the jumper

Note:

An incorrectly configured jumper leads to incorrect displays in the front LEDs. Additionally, it is not possible to display a correct position on the Web user interface!



2.8.2 Installing the backplane

In its state on delivery, the back of the U 100 base device is covered with blind panels:




Figure 2: Position of the blind panel on delivery of U 100

To remove the blind panel, unscrew the two Phillips screws indicated in the above figure and remove the blind panel. The cables now visible must be connected to the backplane coded according to chapter 2.8.1, as shown in the following figure:




Figure 3: Connecting the voltage supply and signal lines

The backplane is now carefully inserted into the free slot of the U 100 base device and screwed in with the Phillips screws of the backplane. Here you must ensure that the cables are not jammed and that the backplane can be installed in the housing with only a small amount of pressure.




Figure 4: Correctly installed backplane

3 General introduction

3.1 Connecting the U 115 to a PC / laptop

When the operating voltage is connected, or after it is inserted into the slot of the base device, the U 115 switches on automatically. After the boot phase (ca. 90 seconds), the two management IP addresses appear in the display, along with other status messages.

If the device is connected to a PC / laptop via one of the network ports, and if the PC / laptop is suitably configured via the network settings, after you enter the IP address in the address line of the Web browser you can start configuring the U 115.

3.2 The Web browser user interface

The Web browser user interface is divided into the top frame, the left frame and the main frame.

The top frame contains general information about the U 115.




Figure 1: General information in the top frame of the Web browser user interface

This information is as follows:

“SW: 3777” indicates the software level of the U 115 EdgePAL,

“FW: 0.2” is the level of the firmware in the U 115 EdgePAL,

“HW: 0” is the hardware version of the U 115 EdgePAL,

“Up: 0d 10h 06m 58s” is the duration of the connection, measured from the moment of the login,

“Time (UTC):” displays the time of the U 115.

The line in bold for the “name”, “location” and “contact” is made up of the settings in the “User” chapter.

In the right section of the top frame, status information for the U 115 is displayed, i.e. in the Web browser user interface, the latest error message is visible.




Figure 2: View of U 115 Display of the Web browser user interface

The left frame

contains the navigation bar for the various submenus, which are described in detail in the following chapters.

In the main frame,

the submenu is displayed according to the selection made in the navigation bar in the left frame.



4 Login

Before the U 115 can be configured there must be a login. This is performed in the "Login" sub-menu.

In the state on delivery, the login data is as follows:

User: admin or user
Password: astro

After correctly entering the login data, you can proceed with the configuration.



Note:

For security reasons, the user names and passwords should be changed from the state on delivery. This prevents unauthorized access.

Only one user / BC 4 can ever be logged into the U 115. At the very bottom of the left frame of the Web browser user interface, the user currently logged in is displayed.

5 Status



When you click on the “Status” submenu in the left frame, the following window appears (example):

ASTRO EdgePAL U115

Status

Time: 24 Mar 2010 10:17:12 UTC. Up: 0d 18h 42m 14s. SW:3805 FW:0.2 HW:0
 Name: ASTRO EdgePAL U115, Location: Headend in Cablecity, Contact: John Doe, admin@example.com

● ASTRO EdgePAL U114
 ● MgmA 192.168.1.144
 ● MgmB 192.168.5.144

Status
 Login
 Main
 Test Gen
 IP RX

 IP RX1
 IP RX2
 IP RX3
 IP RX4

 RF

 RF1.1
 RF1.2
 RF2.1
 RF2.2

 User
 TS Analyzer
 Licensing
 Update
 System Log
 Statistics
 Network

Ethernet

Property	Management A (eth0)	Management B (eth1)	Data A (eth2)	Data B (eth3)
MAC	00:17:72:02:00:e2	00:17:72:03:00:e2	00:17:72:04:00:e2	00:17:72:05:00:e2
Address	192.168.1.144	192.168.5.144	192.168.3.144	192.168.4.144
Subnet	255.255.255.0	255.255.255.0	255.255.255.0	255.255.255.0
Gateway	192.168.1.100	192.168.5.100	192.168.3.100	192.168.4.100
Mode	100 Mbit/s, full duplex	No link	1 Gbit/s, full duplex	No link
Transmit	0.149 Mbps	0.000 Mbps	0.000 Mbps	0.000 Mbps
Receive	0.033 Mbps	0.000 Mbps	148.169 Mbps	0.000 Mbps

IP RX Channels

Channel	Port	Prim. RX IP socket, source	Sec. RX IP socket, source	Encapsulation	FEC	TS Rate	TSID / ONID	Alias
IP_RX1	A, automatic Primary	232.19.100.128:10000.0.0.0.0	0.0.0.0.0.0.0.0.0	1328 bytes 7 packets RTP/UDP/IP	none	38.095 Mbit/s Mult. PCR	1093 / 1	Bayern 1, ARD BR
IP_RX2	A, automatic Primary	232.19.100.129:10000.0.0.0.0	0.0.0.0.0.0.0.0.0	1328 bytes 7 packets RTP/UDP/IP	none	33.862 Mbit/s Mult. PCR	1051 / 1	EinsExtra, ARD
IP_RX3	A, automatic Primary	232.19.100.130:10000.0.0.0.0	0.0.0.0.0.0.0.0.0	1328 bytes 7 packets RTP/UDP/IP	none	33.862 Mbit/s Mult. PCR	1113 / 1	K-TV, MEDIA BROADCAST
IP_RX4	A, automatic Primary	232.19.100.131:10000.0.0.0.0	0.0.0.0.0.0.0.0.0	1328 bytes 7 packets RTP/UDP/IP	L(Cols) 5 D(Rows) 20 Col only	33.868 Mbit/s Mult. PCR	1026 / 1	EXTREMADURA TV, ASTRA

RF Channels

Modulator	Stream	Service	Channel	Frequency	Level	Status
RF1.1	IP_RX2 TSID:1051 ONID:1 Alias:EinsExtra, ARD	arte, ARD SID:28724	S33	399.250000 MHz	0.0 dB	ok
RF1.2	IP_RX2 TSID:1051 ONID:1 Alias:EinsExtra, ARD	EinsPlus, ARD SID:28723	S34	407.250000 MHz	0.0 dB	ok
RF2.1	IP_RX2 TSID:1051 ONID:1 Alias:EinsExtra, ARD	Test-R, ARD SID:28726	S35	415.250000 MHz	0.0 dB	ok
RF2.2	IP_RX4 TSID:1026 ONID:1 Alias:EXTREMADURA TV, ASTRA	Bloomberg Europe TV SID:10067	S36	39.250000 MHz	0.0 dB	ok

Miscellaneous

Property	Value
Temperature 1	39.0 °C
Temperature 2	46.0 °C
Temperature 3	47.0 °C
Supply 1.2 V	1.21 V
Supply 1.5 V	1.52 V
Supply 1.8 V	1.80 V
Supply 2.5 V	2.49 V
Supply 3.3 V	3.35 V
Supply 5.5 V - 6.5 V	5.54 V
Supply 13 V	13.30 V
Fan	9375 RPM
Power Module 1	OK
Power Module 2	OK

System memory

Property	Value
Total size of memory arena	64290052
Number of ordinary memory blocks	59
Space used by ordinary memory blocks	227112
Space free for ordinary blocks	64062916
Size of largest free block	64052820

Ethernet status

Status display of the IP receivers

Status display of the HF output channels

Display of diverse status messages on the module temperature, the internal voltages and the power unit status

Memory status

Here all the relevant data for the status of the U 115 is displayed in detail. No settings can be made here.

Figure 3: Status display in the “Status” submenu



6 Settings for the IP interfaces, IP management and base device

When you click on the “Main” submenu in the left frame, the following window appears (example):

ASTRO EdgePAL U115

Main Settings

Time: 24 Mar 2010 10:34:27 UTC, Up: 0d 18h 59m 29s, SW:3805 FW:0.2 HW:0

Name: ASTRO EdgePAL U115, Location: Headend in Cablecity, Contact: John Doe, admin@example.com

● ASTRO EdgePAL U114

● MgmA 192.168.1.144

● MgmB 192.168.5.144

● user is logged in.

Status

Logout

Main

Test Gen

IP RX

IP RX1

IP RX2

IP RX3

IP RX4

RF

RF1.1

RF1.2

RF2.1

RF2.2

User

TS Analyzer

Licensing

Update

System Log

Statistics

Network

user

on 192.168.1.99

is logged in.

Timeout in 290 s.

IP Interface Settings

Property	Management A (eth0)	Management B (eth1)	Data A (eth2)	Data B (eth3)
MAC	00:17:72:02:00:e2	00:17:72:03:00:e2	00:17:72:04:00:e2	00:17:72:05:00:e2
Active	<input checked="" type="radio"/> on <input type="radio"/> off	<input type="radio"/> on <input checked="" type="radio"/> off	<input checked="" type="radio"/> on <input type="radio"/> off	<input type="radio"/> on <input checked="" type="radio"/> off
Mode	100 Mbit/s, full duplex	No link	1 Gbit/s, full duplex	No link
Address	192 168 1 144	192 168 5 144	192 168 3 144	192 168 4 144
Subnet	255 255 255 0	255 255 255 0	255 255 255 0	255 255 255 0
Broadcast	192.168.1.255	192.168.5.255	192.168.3.255	192.168.4.255
Gateway	192 168 1 100	192 168 5 100	192 168 3 100	192 168 4 100

Note: Please use different IP address settings for each interface.

IP Management Settings

Property	Value
DNS	192 168 1 100
SNTP server	192.168.1.100 0.0.0.0
Time Source	SNTP Server

Note: Use 0.0.0.0 for unused or unknown DNS, or SNTP addresses.

U100 Rack Settings

Property	Value
Base Address	2
Slot Address	1
Power Modules	2

U100 Rack Settings

Property	Value
Base Address	2
Slot Address	1
Power Modules	2

Save 2nd: All settings are saved to an alternative config.
 Load 2nd: All settings are loaded from an alternative config.
 Default: Load factory default settings.
 Reboot: Force reboot.

ASTRO Strobel Kommunikationssysteme GmbH

Figure 4: Overall view

The settings available are described in detail in the following sections.

6.1 Configuration of the IP interfaces

In the area of the user interface displayed below you can activate and deactivate the IP interfaces. The connection type is automatically detected and displayed by the U 115. (Here: 1 GBit/s, full duplex for Data A and 100 MBit/s, full duplex for Management A).

IP Interface Settings

Property	Management A (eth0)	Management B (eth1)	Data A (eth2)	Data B (eth3)
MAC	00:17:72:02:00:e2	00:17:72:03:00:e2	00:17:72:04:00:e2	00:17:72:05:00:e2
Active	<input checked="" type="radio"/> on <input type="radio"/> off	<input type="radio"/> on <input checked="" type="radio"/> off	<input checked="" type="radio"/> on <input type="radio"/> off	<input type="radio"/> on <input checked="" type="radio"/> off
Mode	100 Mbit/s, full duplex	No link	1 Gbit/s, full duplex	No link
Address	192 . 168 . 1 . 144	192 . 168 . 5 . 144	192 . 168 . 3 . 144	192 . 168 . 4 . 144
Subnet	255 . 255 . 255 . 0	255 . 255 . 255 . 0	255 . 255 . 255 . 0	255 . 255 . 255 . 0
Broadcast	192.168.1.255	192.168.5.255	192.168.3.255	192.168.4.255
Gateway	192 . 168 . 1 . 100	192 . 168 . 5 . 100	192 . 168 . 3 . 100	192 . 168 . 4 . 100

Note: Please use different IP address settings for each interface.

Figure 5: IP interface configuration

Changes to the IP addresses must be transferred to the U 115 using the “Submit” button.

Note:



When programming the IP addresses, make sure the addresses are not already allocated in your network. Address conflicts lead to malfunctions in the network.

6.2 IP management configuration

In the IP management configuration, the DNS server and the SNTP server are entered. If a valid entry is made under “SNTP server”, this can be used as a time reference. The MPEG flows (TDT) are additional time references.

IP Management Settings

Property	Value
DNS	192 . 168 . 1 . 100
SNTP server	192.168.1.100 0.0.0.0
Time Source	SNTP Server

Note: Use 0.0.0.0 for unused or unknown DNS, or SNTP addresses.

Figure 6: IP management configuration

6.3 U 100 settings

Under “U 100 Rack Settings” an address can be allocated to the relevant base device. The number of the currently selected slot is displayed below it:

U100 Rack Settings

Property	Value
Base Address	2
Slot Address	1
Power Modules	2

Figure 7: Rack settings

6.4 Saving and loading a configuration, default and reboot

The current configuration of the U 115 is always written to the device using the “Submit” buttons, and is therefore activated immediately. If you want to save the current status, you press the “Save 2nd” button. This current status is then saved on the SD card in the U 115. You can call up this status again using the “Load 2nd” button. Saving the configuration on the local computer or FTP server is explained in the “Update” chapter.

Save settings to flash / Load settings from flash / Default settings / Reboot system

Save 2nd: All settings are saved to an alternative config.
Load 2nd: All settings are loaded from an alternative config.
Default: Load factory default settings.
Reboot: Force reboot.

Figure 8: Saving and loading / default and reboot

The “Default” button is used to restore the factory settings.



Note:

With the factory settings, all the settings apart from the user and network settings of the data and management ports are reset to the state on delivery!

The “Reboot” button restarts the U 115 with the last settings that were entered.

7 Test generator

The U 115 has an integrated test generator for checking the functions of the PAL modulators when no input signal is available yet. The max. data rate that can be set is 67 MBit/s.



The screenshot shows the web interface for the ASTRO EdgePAL U115 Test Generator Settings. The page has a blue header with the ASTRO logo on the left and system information on the right. The main content area is titled 'Test Generator Settings' and contains a table with three rows: 'Date rate' (36.983607 Mbps (910)), 'Packet ID' (230), and 'Packet length' (188). Below the table are 'Submit' and 'Reset' buttons. A left sidebar contains a navigation menu with options like 'Status', 'Logout', 'Main', 'Test Gen', 'IP RX', 'RF', and 'User'. The bottom of the sidebar shows the user 'user' is logged in and the timeout is 297 seconds.

ASTRO EdgePAL U115
Test Generator Settings
 Time: 24 Mar 2010 10:38:37 UTC, Up: 0d 19h 03m 39s, SW:3905 FW:0.2 HW:0
 Name: ASTRO EdgePAL U115, Location: Headend in Cablecity, Contact: John Doe, admin@example.com

● ASTRO EdgePAL U114
 ● MgmA 192.168.1.144
 ● MgmB 192.168.5.144
 ● user is logged in

Test Generator Settings

Property	Value
Date rate	36.983607 Mbps (910)
Packet ID	230
Packet length	188

ASTRO Strobel Kommunikationssysteme GmbH

Status
 Logout
 Main
Test Gen
 IP RX
 IP RX1
 IP RX2
 IP RX3
 IP RX4
 RF
 RF 1.1
 RF 1.2
 RF 2.1
 RF 2.2
 User
 TS Analyzer
 Licensing
 Update
 System Log
 Statistics
 Network
 user
 on 192.168.1.99
 is logged in.
 Timeout in 297 s.

Figure 9: Test generator settings

8 Configuration of the IP inputs

When you click on the “IP RX” submenu in the left frame, the following window appears (example):

Channel	Enable	Port	Encapsulation	Prim. RX IP socket, source	Sec. RX IP socket, source	TSID / ONID	Alias	Link
IP RX1	<input checked="" type="radio"/> on <input type="radio"/> off	A. automatic Primary	RTP/UDP/IP Mult. PCR	232.19.100.128-10000.0.0.0	0.0.0.0.0.0.0.0	1093 / 1	Bayern 1, ARD BR	Play / Play
				232.19.100.128-10000.0.0.0	0.0.0.0.0.0.0.0			Play / Play
IP RX2	<input checked="" type="radio"/> on <input type="radio"/> off	A. automatic Primary	RTP/UDP/IP Mult. PCR	232.19.100.129-10000.0.0.0	0.0.0.0.0.0.0.0	1051 / 1	EinsExtra, ARD	Play / Play
				232.19.100.129-10000.0.0.0	0.0.0.0.0.0.0.0			Play / Play
IP RX3	<input checked="" type="radio"/> on <input type="radio"/> off	A. automatic Primary	RTP/UDP/IP Mult. PCR	232.19.100.130-10000.0.0.0	0.0.0.0.0.0.0.0	1113 / 1	K-TV, MEDIA BROADCAST	Play / Play
				232.19.100.130-10000.0.0.0	0.0.0.0.0.0.0.0			Play / Play
IP RX4	<input checked="" type="radio"/> on <input type="radio"/> off	A. automatic Primary	RTP/UDP/IP Mult. PCR	232.19.100.131-10000.0.0.0	0.0.0.0.0.0.0.0	1026 / 1	EXTREMADURA TV, ASTRA	Play / Play
				232.19.100.131-10000.0.0.0	0.0.0.0.0.0.0.0			Play / Play

Figure 10: Overview of the IP input configuration

Here the four IP inputs to be configured are activated or deactivated, and their current configuration is displayed. You go to the detailed settings either by clicking the relevant channel (e.g. IP RX3) or clicking the relevant submenu in the left frame.

Figure 11: Detailed settings of the IP receiver

Property	Data A (eth2) 1G	Data B (eth3) 1G
Primary Receive IP Port	<input type="text" value="232 19 100 128 10000"/>	<input type="text" value="232 19 100 128 10000"/>
Primary Source Select	<input type="text" value="0 0 0 0"/>	<input checked="" type="checkbox"/> like Data A
Secondary Receive IP Port	<input type="text" value="0 0 0 0 0"/>	<input type="text" value="0 0 0 0 0"/>
Secondary Source Select	<input type="text" value="0 0 0 0"/>	<input type="text" value="0 0 0 0"/>
Property	Data A (eth2) + Data B (eth3)	
Enable	<input checked="" type="radio"/> on <input type="radio"/> off	
Port	<input type="text" value="A"/>	<input type="text" value="automatic"/>
Encapsulation	<input type="radio"/> RTP/UDP/IP <input type="radio"/> UDP/IP <input checked="" type="radio"/> automatic <input type="radio"/> manual	
Bitrate	<input type="radio"/> Single PCR (SPTS) <input type="radio"/> Mult. PCR (MPTS) <input checked="" type="radio"/> automatic <input type="radio"/> manual	
TSID / ONID	<input type="text" value="1093"/>	
Alias manual / automatic	<input type="text" value="Bayern 1, ARD BR"/>	

Enter the IP address and UDP port that will be matched for this channel.
For an IP multicast, use an address in the range 225.0.0.0 to 239.255.255.255.
Use 0.0.0.0 to disable Source Select or Secondary Receive IP.

To enable the greatest possible path redundancy, the U 115 has various different configuration options for the IP receivers. The Data A and Data B ports can be configured completely independently of one another. IGMPv3 enables what is known as “Source Select”, i.e. the IP receiver can request the data from a preferred source.

Figure 12: Setting the Multicast addresses

IP RX1 Channel Settings

Property	Data A (eth2) 1G					Data B (eth3) 1G						
Primary Receive IP:Port	<input checked="" type="radio"/> use	232	19	100	128	10000		232	19	100	128	10000
Primary Source Select		0	0	0	0		<input checked="" type="checkbox"/> like Data A	0	0	0	0	
Secondary Receive IP:Port		0	0	0	0	0		0	0	0	0	0
Secondary Source Select	<input type="radio"/> use	0	0	0	0			0	0	0	0	

The “use” selection box defines the data source used. This data source is defined via the Multicast address and can - if this Multicast address is provided by multiple senders - be used preferentially by the IP receiver. The IP address of the preferred source is entered under “Primary / Secondary Source Select”. If 0.0.0.0 is displayed here, the Source Select function is deactivated. If different signal paths are supplied by the same sending equipment, it can make sense to configure Data B exactly like Data A. This is easily performed by activating “like Data A”.

Figure 13: Settings for the IP input signal format

Property	Data A (eth2) + Data B (eth3)	
Enable	<input checked="" type="radio"/> on	<input type="radio"/> off
Port	A	automatic
Encapsulation	<input type="radio"/> RTP/UDP/IP	<input type="radio"/> UDP/IP
Bitrate	<input type="radio"/> Single PCR (SPTS)	<input type="radio"/> Mult. PCR (MPTS)
TSID / OND	1093	1
Alias manual / automatic		Bayern 1, ARD BR

In the “Enable” line, the IP receiver is activated or deactivated.

In the “Port” line, the data interface is selected (A or B) and the preferred data interface is set. This function enables the U 115 to switch to the second interface after an input signal has failed, and to switch back when the failed signal has been re-established (prefer A or B). If you select the “auto” option, the IP receiver remains on the substitute interface until it is manually switched back, or until this interface also fails.

Under “Encapsulation” the protocol used in the sender is set: RTP/UDP/IP or UDP/IP. However, the U 115 is also able to detect the protocol automatically and evaluate it accordingly.

For the “Bitrate” you can choose between “Single PCR (SPTS)” and “Multiple PCR (MPTS)”. Here the U 115 can also detect the status automatically and process it.

To have a better overview during the configuration of the HF parameters, you have the option of entering an alias. If this entry option is not used, the first service in the transport stream is automatically used as the alias.

9 Configuration of the HF outputs

You go to the overview of the HF parameters via the “RF” submenu in the left frame. All four output channels with the related data on the data flow are displayed, as well as the status of the respective output channel. Here the output channel can be activated or deactivated. If you select “Standby” here, only the HF is deactivated. However, the configuration of the output signal remains active, along with the analysis of the input data flow.

Changes must be written to the device by pressing the “Submit” button.

Figure 14: Overview of the HF parameters

You go to the detailed settings either by clicking the relevant channel (e.g. RF 1.1) or clicking the relevant submenu in the left frame.

In the detailed view of a channel, the programme to be applied in PAL is selected under “Input Selection”. This programme can be applied from any of the four IP receivers.

Figure 15: Output channel setting

In the “Stream Selection” area, the PIDs of the PCR are displayed, along with the PIDs of the selected video and audio stream. The teletext can be selected or deactivated, as can the subtitles.

Stream Selection

Property	Stream	PID (-TTX page)
PCR		110
Video	ISO/IEC 13818-2 Video	110
Audio A	deu ISO/IEC 11172 Audi	120
Audio B	2ch ISO/IEC 11172 Audic	121
Teletext	deu Teletext	130
Subtitling	deu DVB-Subtitling	131

Figure 16: Stream selection

Modulation

Property	Value					
RF	<input type="radio"/> on <input type="radio"/> standby <input type="radio"/> off	Channel C21	Frequency 471.250000 MHz	Level 0.0 dB	Channel Filter <input type="radio"/> on <input type="radio"/> off	
Defaults	PAL BG (A2)					
TV System	Lines 625/50 Hz	Colour PAL	Residual Carrier 11.0 %	Modulation negative		
VPS	<input type="radio"/> on <input type="radio"/> off	CNI Code -1 (-1 is automatic)				
WSS	Mode automatic					<div style="border: 1px solid red; padding: 5px;"> Please select A -> Mono L+R A -> Mono L A -> Mono R A -> Stereo A -> Dual (L is main) A -> Dual (R is main) A -> Automatic A+B -> Dual (static) A+B -> Stereo/Dual (dynamic) Mode A+B -> Stereo/Dual (dyn </div>
Test Lines	CCIR1 automatic	CCIR18 18	CCIR330 330	CCIR331 0	Ramp	
Still Picture	decoder					
OSD Text	4:3					
	16:9					
1st Audio	Modulation FM	Frequency 5.500000 MHz	Level -13.0 dB	Deviation 0.0 dB		
2nd Audio	Modulation FM (A2)	Frequency 5.7421875 MHz	Level -20.0 dB	Deviation 0.0 dB		

Figure 17: Setting the PAL modulator

- “RF” line:
- Activating and deactivating the output signal / Standby: output signal selected and configured, but HF deactivated
 - Selection of the output channel
 - Setting the output level
 - Activating and deactivating the channel filter
- “Defaults” line:
- Selecting the standard used (PAL B/G, PAL D/K, SECAM, Nicam, etc.)
 - In the text input field under “Channel Filter”, in the state on delivery ASTRO has entered the channel filter used
- “TV System” line:
- Display the number of lines and the picture frequency
 - Display the colour standard
 - Display the residual carrier
 - Display the modulation start
 - Correspond respectively to the standard selected in the “Defaults” line
- “VPS” line:
- Activating and deactivating the VPS signal
 - Enter the CNI (Country & Network Identifier)
- “WSS” line:
- Select the WSS mode: off, 16:9, 4:3, decoder and automatic
- “Test Lines” line:
- Enter the picture lines into which the respective test line is to be keyed in
- “Still Picture” line:
- Reserved for future applications
- “OSD Text” line:
- The text entered here is keyed into the current picture as OSD text
- “1st Audio” and “2nd Audio” lines:
- Setting the audio mode and the audio hub (deviation)



10 User management

You reach the user management by clicking on the “User” submenu. The U 115 allows you to create four different users. In the state on delivery, “admin”, “user” and “bc4” are created, all with the password “astro”.



Note:

For security reasons, the user names and passwords should be changed from the state on delivery. This prevents unauthorized access.

In the “Timeout” line the minutes are entered until the U 144 automatically logs the user out if no configuration change has been registered during this period.

In the lower area of the “User Administration” table, you can enter the name, location and responsible contact person. These entries also appear in the top frame.

ASTRO EdgePAL U115
User Administration
 Time: 24 Mar 2010 11:55:17 UTC. Up: 0d 20h 20m 19s. SW:3805 FW:0.2 HW:0
 Name: ASTRO EdgePAL U115, Location: Headend in Cablecity, Contact: John Doe, admin@example.com

● ASTRO EdgePAL U114
 ● MgmA 192.168.1.144
 ● MgmB 192.168.5.144
 ● user is logged in

User Administration

Property	Username	New Password	Retype New Password	Delete
Account 1	admin			
Account 2	user			<input type="checkbox"/>
Account 3	bc4			<input type="checkbox"/>
Account 4				<input type="checkbox"/>

Timeout: 5 minutes

Name: ASTRO EdgePAL U114

Location: Headend in Cablecity

Contact: John Doe, admin@example.com

Leave input box empty to keep settings. To disable account 2, 3 or 4 set an empty username. Please use no passwords shorter than five characters

Note: There is no hidden password. Do not forget your password or you will be locked out.

ASTRO Strobel Kommunikationssysteme GmbH


user on 192.168.1.99 is logged in.
 Timeout in 296 s.

Figure 18: User management

Changes must be transferred to the U 115 using “Submit”.

11 Transport Stream (TS) Analyzer

The U 115 can be equipped with a Transport Stream Analyzer by obtaining a licence. This Analyzer displays the structure of the MPEG2 TS, from the tables to the individual PID and its service. You click on the “TS Analyzer” submenu to reach the selection of the transport stream to be analysed. When you select a TS in the “Analyze” line and press the “Submit” button, the selected transport stream is analysed.



ASTRO EdgePAL U115 TS Analyzer

Time: 24 Mar 2010 11:56:31 UTC. Up: 0d 20h 21m 33s. SW:3805 FW:0.2 HW:0
 Name: ASTRO EdgePAL U115. Location: Headend in Cablecity. Contact: John Doe, admin@example.com

● ASTRO EdgePAL U114
 ● MgmA 192.168.1.144
 ● MgmB 192.168.5.144
 ● user is logged in

TS Analyzer

Alias	Bayern 1, ARD BR	Eins Extra, ARD	K-TV, MEDI A, BROA DCAS T	EXTR EMAD URA TV, ASTRA	ASTRO
TSID	1093	1051	1113	1026	65535
ONID	1	1	1	1	65535
Source	IP RX1	IP RX2	IP RX3	IP RX4	Test Gen.
Analyze	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>

Standard	Table			
MPEG	<input checked="" type="checkbox"/> PAT	<input checked="" type="checkbox"/> CAT	<input type="checkbox"/> TSDT	<input checked="" type="checkbox"/> PMTs
DVB	<input checked="" type="checkbox"/> NIT actual	<input type="checkbox"/> NIT other (only first found)	<input checked="" type="checkbox"/> SDT actual	<input type="checkbox"/> SDT other (only first found)
	<input type="checkbox"/> EIT actual present/following	<input type="checkbox"/> EIT actual schedule	<input type="checkbox"/> BAT (only first found)	<input type="checkbox"/> RST (only first found)
	<input checked="" type="checkbox"/> TDT	<input type="checkbox"/> TOT		

Please be patient until measurements are finished. (e.g. EIT may take a long time.)

ASTRO Strobel Kommunikationssysteme GmbH

Figure 19: Transport Stream (TS) Analyzer view

The optionally available TS Analyzer provides an effective way of checking that the IP input signal is complete, as regards the services / tables it contains. When an analysis has been started, it can take several minutes to complete. In particular, the analysis of the EIT (Event Information Table) can take somewhat longer.

A data stream can be received with CBR (Constant Bit Ratio) in the U 261 gateway, or with VBR (Variable Bit Ratio). In any case, CBR is used in MPTS (Multiple Program Transport Stream), but also in SPTS (Single Program Transport Stream). However, SPTS can also be sent with VBR.

Under “Packet Mode” you can choose between “continuous” or “burst” for the configuration of the respective ASI outputs after the IP RX.

The TSID and ONID are displayed according to the transport stream selected, and an alias can be entered for a better overview of the transport streams (see also Figure 11). If no alias is entered, the name of the first service of the transport stream appears.

12 Licensing

Some functions of the U 115 (e.g. the TS Analyzer) must be activated using a licence key. The licence key can be obtained from ASTRO along with the function. The text sent is then copied into the text input field and transferred to the device using “Submit”.





Figure 20: Input mask for licence key

To order additional licences, you must enter the MAC address of the device. You will find the MAC address on the Web browser interface, in the “Licensing” submenu (HWID). After the MAC address is passed on, the licence keys are generated at the ASTRO company and issued by e-mail or on a CD.

The format of a licence key is a text document (e.g. Lic001772000222.txt). You can use copy / paste to copy the key(s) into the input mask and press the “Submit” button to transfer the licences to the U 115. If the licence is valid, this is confirmed with the message “License is valid”. An error message is displayed for an invalid licence.

13 Software update / saving & loading a configuration

When you click on the “Update” submenu in the left frame, the following window appears (example):



ASTRO EdgePAL U115
Software Update

Time: 24 Mar 2010 11:59:08 UTC. Up: 0d 20h 24m 10s, SW:3805 FW:0.2 HW:0
 Name: **ASTRO EdgePAL U115**, Location: **Headend in Cablecity**, Contact: **John Doe, admin@example.com**

● ASTRO EdgePAL U114
 ● MgmA 192.168.1.144
 ● MgmB 192.168.5.144
 ● user is logged in

Software Update

Property	Value
(T)FTP Server address	192.168.1.40
Protocol	<input type="radio"/> FTP <input checked="" type="radio"/> TFTP
FTP Username (e.g. anonymous)	anonymous
FTP Password (e.g. guest)	guest
Path	/u11x/
File	Please select

ASTRO Strobel Kommunikationssysteme GmbH

Figure 21: Action selection in the “Software Upgrade” submenu

Here you have the option to store the configuration of the U 115 on an FTP server.

Clicking on the “Update” submenu takes you to the settings for the U 115 software update. In the “(T)FTP Server address” line you enter the (T)FTP server address at which the current software for the U 115 is stored.

In the “Protocol” line you can choose between “FTP” (File Transfer Protocol) and “TFTP” (Trivial File Transfer Protocol). If you choose the “TFTP” option, it is not necessary to enter the user name and the password.

Under “Path” you must enter the path under which the U 115 software for the update was stored. You must ensure that the software is stored in the path entered (with “/” at the start and the end), otherwise no update is performed. You must also ensure that any firewall installed allows (T)FTP communication.

The “Update” submenu also provides the option to save the configuration of the U 115 on an FTP server, or to load a configuration into the U 115. Loading a configuration into the U 115 does not affect the settings of the IP interfaces.

13.1 Update using example of a TFTP server for Windows

If no fixed (T)FTP server is set up for the update, you also have the option to transfer locally saved update files onto the device. Here it is recommended to use a TFTP programme. The procedure is described in the following section using the “Tftpd32” programme.




Figure 22: Example view of the U 115 update folder with update files and “tftpd32” TFTP programme

The “tftpd32” programme is started directly from the folder with the U 115 update files. In the window that appears, you first press the “Settings” button, then enter the settings according to Figure 21:




Figure 23: Settings for the tftpd32 TFTP programme

To start the update, the IP address of the local computer must be entered as the server address in the line “(T)FTP Server address” (Figure 23), and the protocol set to TFTP. Thus it is no longer necessary to enter a user name and a password. In the “File” line you now select the option “Update” and press the “Submit” button to start the update.



NOTE:

A reboot or a network failure during an update process can cause the U 115 software to crash irrevocably. The device then has to be returned to ASTRO for repair.

14 System log

Clicking on the “System Log” submenu takes you to the log of the U 115. All the procedures relevant to the operation of the device are documented here. Additionally, the SNMP settings are made here (defining the trap recipients, the trap community & the trap filter). Also, the “Log file filter” line can be used to define which events lead to an entry in the log.

ASTRO EdgePAL U115 System Log

Time: 24 Mar 2010 12:01:13 UTC, Up: 0d 20h 26m 15s, SW:3805 FW:0.2 HW:0
 Name: ASTRO EdgePAL U115, Location: Headend in Cablecity, Contact: John Doe, admin@example.com

System Log Settings

Property	Value 1	Value 2	Value 3	Value 4
SNMP trap receiver	0.0.0.0	0.0.0.0	0.0.0.0	0.0.0.0
SNMP trap community	public	public	public	public
SNMP trap filter	<input checked="" type="checkbox"/> Emergency	<input checked="" type="checkbox"/> Alert	<input checked="" type="checkbox"/> Critical	<input checked="" type="checkbox"/> Error
Log file filter	<input checked="" type="checkbox"/> Emergency	<input checked="" type="checkbox"/> Alert	<input checked="" type="checkbox"/> Critical	<input checked="" type="checkbox"/> Error

Note: Use 0.0.0.0 for unused or unknown SNMP addresses.

System Log

Refresh Check box to clear log on refresh

System log in CSV format: [log.csv](#) (Use right click and "save as" to save locally.)

IP configuration in XML format: [ip.xml](#)
 System settings in XML format: [settings.xml](#)
 System status in XML format: [status.xml](#)
 Module info in XML format: [module.xml](#)
 Use right click and "save as" to save locally.

```

number,time,uptime,user,source,severity,message
1,24 Mar 2010 11:55:11 UTC,0d 20h 20m 13s,user,192.168.1.99,info,Login
2,24 Mar 2010 10:57:14 UTC,0d 19h 22m 16s,system,local,info,Login timeout
3,24 Mar 2010 10:52:14 UTC,0d 19h 17m 16s,user,192.168.1.99,info,TV RF 1 changed
4,24 Mar 2010 10:52:02 UTC,0d 19h 17m 04s,user,192.168.1.99,info,TV Service 1 changed
5,24 Mar 2010 10:52:02 UTC,0d 19h 17m 04s,user,192.168.1.99,info,TV RF 1 changed
6,24 Mar 2010 10:52:01 UTC,0d 19h 17m 03s,user,192.168.1.99,info,TV Service 1 changed
7,24 Mar 2010 10:40:22 UTC,0d 19h 05m 24s,user,192.168.1.99,info,Test Gen changed
8,24 Mar 2010 10:34:11 UTC,0d 18h 59m 13s,user,192.168.1.99,info,Login
9,24 Mar 2010 10:16:05 UTC,0d 18h 41m 07s,admin,192.168.1.110,info,Logout
10,24 Mar 2010 09:38:03 UTC,0d 18h 03m 05s,system,local,debug,alive - free: 64062324
11,24 Mar 2010 08:38:03 UTC,0d 17h 03m 05s,system,local,debug,alive - free: 64062364
  
```

Figure 24: System log settings

The SNMP MIBs available are stored on the U 115 and can be downloaded from the device.

The operations in the system log are sorted by the time they occurred. To delete the log file, you set the flag for “Check box to clear log on refresh”, then click on the “Refresh” button. The first entry in the log is then the deletion operation, together with the time and the user account, as well as the IP address of the user.

NOTE:

- Downloading the IP configuration via the link “ip.xml”
- System settings via the link “settings.xml”
- System entries via the link “status.xml”
- Module information via the link “module.xml”





15 Statistics

Clicking on the “Statistics” submenu takes you to the statistics for the data transfer of the U 115. Here all the statistics relevant to the operation of the device and its analysis are displayed.

ASTRO EdgePAL U115

Statistics

Time: 24 Mar 2010 12:03:23 UTC, Up: 0d 20h 28m 25s, SW:3805 FW:0.2 HW:0
 Name: ASTRO EdgePAL U115, Location: Headend in Cablecity, Contact: John Doe, admin@example.com

- ASTRO EdgePAL U114
- MgmA 192.168.1.144
- MgmB 192.168.5.144
- user is logged in

Status
Logout
Main
Test Gen
IP RX

IP RX1
IP RX2
IP RX3
IP RX4

RF

RF1.1
RF1.2
RF2.1
RF2.2

User
TS Analyzer
Licensing
Update
System Log
Statistics
Network

user
on 192.168.1.99
is logged in

Timeout in 297 s.

Ethernet bandwidth

Property	Management A (eth0) 100M	Management B (eth2) 1G	Data A (eth2) 1G	Data B (eth3) 1G
Transmit	0.085 Mbps	0.000 Mbps	0.000 Mbps	0.000 Mbps
Receive	0.032 Mbps	0.000 Mbps	148.141 Mbps	0.000 Mbps

Ethernet frames

Property	Data A (eth2) 1G	Data B (eth3) 1G
Total frames sent by host	2656	0
Total frames sent to host	3288	0
Total exception frames sent to host	4741	0
Total errored frames received	0	0
Total frames discarded by deencapsulator	2146306	0
Total frames discarded because of lack of buffers	0	0
Total receive frames forwarded to IP RX 1 / per sec.	265918730 / 3615	0 / 0
Total receive frames forwarded to IP RX 2 / per sec.	236371031 / 3213	0 / 0
Total receive frames forwarded to IP RX 3 / per sec.	236370873 / 3213	0 / 0
Total receive frames forwarded to IP RX 4 / per sec.	248190676 / 3374	0 / 0

Ethernet RX

Channel	Encap	TS Rate	Buffer depth	FEC	Valid	Missing	Fixed	Duplicate	Reordered	Out of range
1	1328 bytes 7 packets RTP/UDP/IP	38.059 Mbit/s Mult. PCR	344 Frames 67.2 % 95.5 ms	none	265864245	0	0	2207	0	0
2	1328 bytes 7 packets RTP/UDP/IP	33.831 Mbit/s Mult. PCR	355 Frames 69.3 % 110.9 ms	none	236323069	0	0	1460	0	0
3	1328 bytes 7 packets RTP/UDP/IP	33.831 Mbit/s Mult. PCR	355 Frames 69.3 % 110.6 ms	none	236323121	0	0	1257	0	0
4	1328 bytes 7 packets RTP/UDP/IP	33.831 Mbit/s Mult. PCR	355 Frames 69.3 % 110.9 ms	L(Cols) 5 D(Rows) 20 Col only	236323131	0	0	2499	0	0

ASTRO Strobel Kommunikationssysteme GmbH

Figure 25: Statistics for the data transfer

26

Operating Manual U 115 quad IP / PAL converter

16 Network properties

You reach the network properties by clicking the “Network Monitor” submenu. The properties displayed are purely for information purposes, and are used to describe the network.

ASTRO EdgePAL U115

Network Monitor

Time: 24 Mar 2010 12:07:33 UTC. Up: 0d 20h 32m 35s. SW:3805 FW:0.2 HW:0
 Name: ASTRO EdgePAL U115, Location: Headend in Cabcicity, Contact: John Doe, admin@example.com

- ASTRO EdgePAL U114
- MgmA 192.168.1.144
- MgmB 192.168.5.144
- user is logged in

- Status
- Logout
- Main
- Test Gen
- IP RX
- IP RX1
- IP RX2
- IP RX3
- IP RX4
- RF
- RF1.1
- RF1.2
- RF2.1
- RF2.2
- User
- TS Analyzer
- Licensing
- Update
- System Log
- Statistics
- Network

user on 192.168.1.99 is logged in.
Timeout in 289 s.

Logical Interfaces

Interface	Status	
eth2	Flags	UP BROADCAST RUNNING SIMPLEX MULTICAST
	Address	192.168.3.144
	Broadcast	192.168.3.255
eth0	Flags	UP BROADCAST RUNNING SIMPLEX MULTICAST
	Address	192.168.1.144
	Broadcast	192.168.1.255
lo0	Flags	UP LOOPBACK RUNNING MULTICAST
	Address	127.0.0.1

Protocols

IPv4	ICMPv4	IGMP	UDP	TCP
	Received	Received		Connections
	ECHO 622	Total 1179		Initiated 3680
Received	ECHO REPLY 0	Too long 0		Accepted 8675
Total 83463	UNREACH 0	Too short 0		Established 12355
Bad 1179	REDIRECT 0	Bad sum 0	Received	Closed 12383
Reassembled 0	Other 0	Queries 1179	Total 212	Received
Delivered 81909	Bad 0	Bad queries 0	Bad 128	Packets 81076
Sent	Sent	Reports 0	Sent	Data Packets 22283
Total 80799	ECHO 0	Bad reports 0	Total 84	Bytes 269736
Raw 0	ECHO REPLY 622	Our reports 0		Sent
Fragmented 0	UNREACH 0	Sent		Packets 77727
	REDIRECT 0	Reports 2368		Data Packets 32005
	Other 0			Bytes 30301825

Mbufs

Summary	Types
Mbufs 19	
Clusters 9	
Free Clusters 8	FREE 17
Drops 0	DATA 2
Waits 0	HEADER 0
Drains 0	SONAME 0
Copy Fails 0	FTABLE 0
Pullup Fails 0	

ASTRO Strobel Kommunikationssysteme GmbH

Figure 26: Example view of the network properties in the “Network Monitor” submenu



17 Logout

Clicking on the “Logout” submenu (only available when you are logged in) takes you to the logout of the U 115.

User Logout

Are you sure?




Figure 27: Logging out of the U 115

If you confirm the request by clicking “Yes”, you are logged out. No further settings can be made without logging in again, but you do have the option to view the settings of the U 115. However, the setting elements are inactive.

18 Technical data

Type		U 100 - 48	U 100 - 230
Order number		380 100	380 101
Network interfaces (forwarded passively to U 1xx)			
Management		2 x 100 Base-T Ethernet (RJ 45)	
Data		2 x 1000 Base-T Ethernet (RJ 45)	
Protocol		IEEE802.3 Ethernet, RTP, ARP, IPv4, TCP/UDP, HTTP, SNTP, IGMPv3	
Transport stream processing			
TS capsulation		UDP, UDP / RTP, 1-7 packets, FEC	
Transport stream processing		transparent (188 or 204 packets)	
Control and management			
Properties		Control via HTTP / WEB	
Protocol		HTTP / SNMP (error messages)	
General data			
Input voltage	[V]	- 48 V DC	230 V AC
Power consumption	[W]	depends on equipment	
Dimensions		19" / 1 HE	

Type		U 115
Order number		380 115
Network interfaces (forwarded passively from U 100)		
Management		2 x 100 Base-T Ethernet (RJ 45)
Data		2 x 1000 Base-T Ethernet (RJ 45)
Protocol		IEEE802.3 Ethernet, RTP, ARP, IPv4, TCP/UDP, HTTP, SNTP, IGMP
Transport stream processing		
TS decapsulation		UDP, UDP / RTP, 1-7 packets, FEC
Transport stream processing		transparent (188 or 204 packets)
Decoding		
Video		MPEG 2 Main Profile @ Main Layer MP@ML and H.264 MP @ L30 (SD)
Audio		2x MPEG 1 Layer 1/2, Mono / Stereo, 2-channel sound / Audio Description
Data		Teletext, VPS, WSS, subtitles, DVB subtitling
PAL modulator		
Connections	[Ω]	75, 2x F-sockets
Frequency range	[MHz]	47 - 862, digitally modulated
Output level	[dBμV]	118
Reflexion loss	[dB]	≥ 16
Secondary wave separation	[dB]	≥ 65
Intercarrier signal-to-noise voltage ratio	[dB]	typ. 60
Stereo cross talk	[dB]	> 55
Residual carrier accuracy	[%]	1
TV standard		PAL/SECAM, B/G/D, SECAML, A2/NICAM
Video signal-to-noise ratio	[dB]	66, limited evaluation
General data		
Power consumption	[W]	ca. 30
Permitted ambient temperature	[°C]	0... +45

Technical improvement, changes to design and errors reserved.



ASTRO Strobel Kommunikationssysteme GmbH
Olefant 1-3, D-51427 Bergisch Gladbach (Bensberg)
Tel.: 02204/405-0, Fax: 02204/405-10
E-mail: kontakt@astro-kom.de, www.astro-kom.de